

Cetol® UV Interior Clear Matte Wood Finish SIK09003

DESCRIPTION

Cetol® UV (Ultraviolet) Interior Wood Finish

is a unique waterborne product designed to protect interior wood yet leave no color or sheen on the surface. When a beautiful, natural appearance is desired, use Cetol UV Interior Wood Finish (recommended for use on light-colored woods only).

FEATURES

- Premium UV Protection for Interior Wood.
- For Ceilings, Paneling, Logs and Saunas

COMPOSITION

- Acrylic Resin
- Not manufactured with lead or mercury containing materials

SHIPPING

Freight Classification:

Paint, Freezable

Packaging:

1 gallon (3.785 L) 5 gallons (18.925 L)

Flash Point:

None

SPECIFICATION DATA

Color:

Clear Do Not Tint

Clean-up Solvent:

Soap & Water

*Density:

8.59 lbs/gal (1.03 kg/L)

VOC:

350 g/L (2.92 lbs/gal) maximum
Refer to MSDS for regulatory VOC content of complete product line

*Solids:

Volume - 22% +/- 1% Weight - 25% +/- 1%

Practical Coverage:

Apply at 400-500 sq ft/gallon (10-12 m²/L). Actual coverage may vary depending on the type, age and texture of the wood and application method.

Flash Point:

None

Dry Time 77°F (25°C) & 50% RH:

To touch - 1 hour
To recoat - 2-4 hours
Low temperature, high humidity or poor
ventilation will increase these times. Avoid
heavy abrasions immediately following
application

Shelf Life:

2 years maximum - unopened



SURFACE PREPARATION

GENERAL SURFACE PREPARATION FOR NEW OR

UNFINISHED WOOD: All wood surfaces must be thoroughly clean, dry and free of dirt, grease, grime, mildew, mill glaze and previous coatings before applying **Cetol UV Interior Wood Finish**.

- Remove hardware. Any hardware that cannot be removed should be covered with painters tape.
- Clean surface with a solution of four (4) ounces of 100% powdered Tri-Sodium Phosphate (TSP) or phosphate-free substitute in one gallon of warm water.
- Wipe surface with a damp cloth or sponge and clear water to remove any residue and allow to dry. Do not allow solution to dry on the wood surface.
- Fill any nail holes or cracks with a good quality acrylic wood filler matching the color of the wood. Do not use oil-based fillers, putties or wax sticks. Allow to dry completely before sanding.
- 5. Sand the surface with 150-180 grit sand paper. Always sand with the grain for a smoother surface and no sanding marks. Remove sanding dust with vacuum, then wipe surface with a damp cloth to remove any remaining particle. For a smoother final finish sand surface again with 180-220 grit sandpaper and wipe clean.

EXOTIC HARDWOOD - Ipe, mahogany, iron wood, tiger wood and

teak woods exhibit a dense cell structure which may reduce the ability of a coating to penetrate the wood surface. Clean and prepare all wood surfaces as specified under **GENERAL SURFACE PREPARATION**. Immediately prior to applying coating, wipe surface with acetone.

PREVIOUSLY COATED WOOD - Previous stains, varnishes or sealers must be completely and thoroughly removed prior to application of **Cetol UV Interior Wood Finish**. After removal of previous coatings, clean and prepare surface as specified under **GENERAL SURFACE PREPARATION**.

WARNING! If you scrape, sand, or remove old paint, you may release lead dust. LEAD IS TOXIC. EXPOSURE TO LEAD DUST CAN CAUSE SERIOUS ILLNESS, SUCH AS BRAIN DAMAGE, ESPECIALLY IN CHILDREN. PREGNANT WOMEN SHOULD ALSO AVOID EXPOSURE. Wear an NIOSH-approved respirator to control lead exposure. Clean up carefully with a HEPA vacuum and a wet mop. Before you start, find out how to protect yourself and your family by contacting the National Lead Information Hotline at 1-800-424-LEAD or log on to www.epa.gov/lead.

DIRECTIONS FOR USE

APPLICATION:

CAUTION: Do not apply Cetol UV Interior Wood Finish over stain; use on bare, light colored wood only.

- 1. Stir before and periodically during application.
- 2. Do not thin.
- 3. Apply between 50° F (10° C) 95° F (35° C).
- Do not apply in direct sunlight, may cause uneven color because of shortened open time and poor penetration.
- Apply Cetol UV Interior Wood Finish in the direction of the wood grain using a premium quality nylon-polyester brush.
- 6. Allow first coat to dry four to six hours.
- Lightly sand with 220 grit sandpaper or a fine scuffing pad and remove sanding dusting with a dry cloth.
- Apply a second coat of Cetol UV Interior Wood Finish. A third coat may be applied to high wear areas after second coat has dried for four to six hours.

TWO COAT APPLICATION IS RECOMMENDED FOR OPTIMAL PERFORMANCE.

COVERAGE:

On smooth surfaces, 400-500 sq ft/gallon (10-12 m²/L). Actual coverage may vary depending on the type, age and texture of the wood.

DRY TIME @ 77°F (25°C) & 50% RH:

Dries to touch one hours and to recoat in two to four hours. Low temperature, high humidity, thick films or poor ventilation will increase these times. Avoid heavy abrasions immediately following application.

CLEANUP AND STORAGE:

Clean tools immediately with warm soapy water. Clean spills right away with a damp cloth.

MAINTENANCE PROCEDURES:

The longevity of the coat depends on the amount of daily wear and exposure to ultraviolet light. Clean and prepare surface as specified under **GENERAL SURFACE PREPARATION** reducing the cleaning solution to two (2) ounces of 100% powdered Tri-Sodium Phosphate (TSP) or phosphate-free substitute. Apply one or two coats depending on the extent of the wear.

PRECAUTIONS

DANGER! HARMFUL IF INHALED. MAY CAUSE CENTRAL NERVOUS SYSTEM EFFECTS, INCLUDING DIZZINESS, HEADACHE OR NAUSEA. CAUSES EYE, SKIN AND RESPIRATORY TRACT IRRITATION. HARMFUL IF SWALLOWED. OVEREXPOSURE MAY CAUSE LIVER, KIDNEY DAMAGE. USE ONLY WITH ADEQUATE VENTILATION. KEEP OUT OF THE REACH OF CHILDREN. NOTICE: This product contains solvents. Reports have associated repeated and prolonged occupational overexposure to solvents with permanent brain and nervous system damage. Intentional misuse by deliberately concentrating and inhaling the contents may be harmful or fatal. For emergency information call (800) 545-2643. For additional safety information, refer to the Material Safety Data Sheet for this product. Keep away from heat, sparks and fame. Do not smoke. Vapors may ignite. Extinguish all flames, burners, stoves, heaters and pilot lights and disconnect all electrical motors and applicances before use and until all vapors are gone. Prevent build-up of vapors by opening all windows and doors to achieve cross-ventilation. If sanding, wear a dust mask to avoid breathing of sanding dust. Do not breathe vapors or spray mist. Ensure fresh air entry during application and drying. Avoid contact with eyes and skin. If you experience eye watering, headaches, or dizziness, leave the area. If properly used, a respirator may offer additional protection. Obtain professional advice before using. Close container after each use. FIRST AID: For skin contact, wash thoroughly with soap and water. If any product remains, gently rub with petroleum jelly, vegetable or mineral/baby oil then wash again with soap and water. Repeat as needed. Remove contaminated clothing. For eyec contact, flush immediately with plenty of water for at least 15 minutes. Get medical attention. If swallowed, get medical attention immediately. If inhalation causes discomfort, remove to fresh air. If discomfort persists or breathing difficulty occurs, get medical attention. KEEP FROM FREEZING.





I-866-SIKKENS • www.sikkens.us

LIMITATION OF LIABILITY To the best of our knowledge, the technical data contained herein are true and accurate at the date of issuance but are subject to change without prior notice. We guarantee our product to conform to the specifications contained herein. WE MAKE NO OTHER WARRANTY OR GUARANTEE OF ANY KIND, EXPRESS OR IMPLIED, INCLUDING MERCHANTABILITY AND FITNESS FOR PARTICULAR PURPOSE. Liability, if any, is limited to replacement of the product or refund of the purchase price. LABOR OR COST OF LABOR AND OTHER CONSEQUENTIAL DAMAGES ARE HEREBY EXCLUDED.

SIK09003-2 - 2/13 Page 2 of 2